

Hazard Alarm System Scheuermatthof



Holiday apartment 2nd floor (top floor/attic)

- Check if there is any fire or smoke.
- Talk to the guests in the ground floor and 1st floor if necessary.
- **The siren sounds for 5 minutes and then switches itself off automatically.**
- The alarm centre is located in the holiday house on the 1st floor. **The alarm can only be confirmed prematurely there with the code 6789.** If the holiday house is not occupied, you must wait 5 minutes until the alarm siren stops by itself. **The siren continues to flash for some time.**

Holiday home (Ground floor, upper floor and barn)

- Check if there is any fire or smoke.
- Talk to the guests in the apartment at the 2nd floor if necessary.
- **Without confirmation at the control panel, the siren sounds for 5 minutes.**

The alarm is NOT automatically forwarded to the fire brigade! In the event of a fire, first bring yourself and those in need of help to safety. Then call the emergency number 112 from a secure telephone.

False alarm

- The alarm centre is located in the holiday home on the 1st floor. The alarm can only be confirmed prematurely there. If the holiday home is not occupied, you must wait 5 minutes until the alarm siren stops by itself. To confirm the alarm, open the flap on the control panel of the control centre and enter the **confirmation code 6789**. **The alarm siren stops and continues to flash for some time.**
- The most common cause of alarms is a sabotage alarm. This is triggered as soon as someone manipulates one of the smoke detectors and removes it from the ceiling. The display of the control panel on the 1st floor indicates by which detector the alarm has been triggered.
- Another common cause of false alarms are the detectors in the kitchen (ground floor) and in the living room (2nd floor). These detectors are often triggered by smoke from the oven or cooking fumes from the kitchen. In this case, ventilate the room well.

If you have any questions or need further information, please contact:

- the caretaker Mr. Schiner => +49 (0) 1523 6813373
- the landlord Mr Morgenthaler => +49 (0) 761 5191684